



1. Insulation
2. Fixing.
3. Adhesive and mesh.
4. Render/basecoat.
5. Window head bead with mesh
6. Window reveal bead.

Remove existing cover vent:
 A. Install a proprietary ventilation cover With clip or
 B. Attach vent cover with double sided and expanding tape.

The vent should be sleeved with basecoat and mesh to avoid water ingress.

DRAWING TITLE: Extending air bricks and existing ventilation.



EWI Pro Insulation Systems LTD.
 Kingston Business Centre Unit 1
 Fullers Way South
 Chessington KT9 1DQ

DRAWING No: EP-031

DATE: 12-02-2014

SCALE: NTS