



- 1. Existing window sill.
- 2. Double Sided sponge tape.
- 3. Screw/Fixing for under sill profile.
- 4. Under sill T-shape bead.
- 5. Under sill profile.
- 6. Mechanical Fixing.
- 7. Insulation Adhesive.

- 8. Insulation.
- 9. Basecoat + Fibreglass Mesh.
- 10. Topcoat.

DRAWING TITLE: Installing undersill profile to existing window sill

DRAWING No: EP - 011

DATE: 11-02-2014

SCALE: NTS

\*For fixing patterns, please refer to relevant diagrams.



EWI Pro Insulation Systems LTD.  
 Kingston Bussines Centre Unit1  
 Fullers Way South  
 Chessington KT9 1DQ