



1. Facia board + gutter.
2. Expanding tape or Undersill bead (T-shape).
3. Verge trim (downside profile).
4. Verge trim (downside profile) fixing to substrate.
5. Insulation Adhesive.
6. Mechanical Fixing.
7. Insulation.
8. Basecoat + Fibreglass Mesh.
9. Topcoat.

DRAWING TITLE: Down profile verge-trim installed flush to eaves with no roof overhang



DRAWING No: EP - 013

DATE: 11-02-2014

SCALE: NTS

*For fixing patterns, please refer to relevant diagrams.

EWI Pro Insulation Systems LTD.
Kingston Business Centre Unit1
Fullers Way South
Chessington KT9 1DQ