



1. Facia board.
2. Gutter System.
3. Verge trim (upstand) profile screwed through facia board into wall.
4. Verge trim (upstand profile).
5. Expanding tape or undersill bead.
6. Insulation Adhesive.
7. Mechanical Fixing.
8. Insulation.
9. Basecoat + Fibreglass Mesh.
10. Topcoat.

DRAWING TITLE: Up profile verge-trim installed flush to eaves with no roof overhang

DRAWING No: EP - 014

DATE: 11-02-2014

SCALE: NTS

*For fixing patterns, please refer to relevant diagrams.



EWI Pro Insulation Systems LTD.
Kingston Business Centre Unit 1
Fullers Way South
Chessington KT9 1DQ