



NOTE:

- Flashing cut into the insulation system and covered by water tight profiling.
- You can use a down sloping verge trim to cap over the led.
- OR: take flash and screw behind the starter track of the main system.

- | | |
|---|---------------------------------------|
| 1. Insulation Adhesive. | 8. Verge trim profile + screw fixing. |
| 2. Insulation. | 9. XPS Insulation. |
| 3. Mechanical Fixing. | 10. LED flashing. |
| 4. Basecoat + Fibreglass Mesh. | |
| 5. Topcoat. | |
| 6. Starter track + clip-on bead + fixing. | |
| 7. Expanding double-sided tape. | |

DRAWING TITLE: Insulation installed under flashing profile to a pitched roof abutment



DRAWING No: EP - 017

DATE: 09-02-2022

SCALE: NTS

REFERENCES:
WRD-RA001

EWI Pro Insulation Systems LTD.
Kingston Bussines Centre Unit1
Fullers Way South
Chessington KT9 1DQ