



1. Insulation.
2. Insulation Adhesive.
3. Mechanical Fixing.
4. Corner bead with return mesh (flat or 4mm profile).
5. Basecoat + Fibreglass Mesh.
6. Topcoat.

NOTE:

Mechanical fixings installed at least 100mm from the corners.

DRAWING TITLE: External corner installation detail



DRAWING No: EP - 018

DATE: 19-02-2014

SCALE: NTS

\*For fixing patterns, please refer to relevant diagrams.

EWI Pro Insulation Systems LTD.  
Kingston Business Centre Unit1  
Fullers Way South  
Chessington KT9 1DQ