



1. Powder coated aluminium profile.
2. Expanding tape.
3. Stop bead with return mesh or T-shape undersill bead.
4. Insulation Adhesive.
5. Insulation.
6. Basecoat + Fibreglass mesh.
7. Topcoat.

DRAWING TITLE: External insulation installed to a parapet wall with powder coated aluminium capping



DRAWING No: EP - 024

DATE: 30-09-2014

SCALE: NTS

*For fixing patterns, please refer to relevant diagrams.

EWI Pro Insulation Systems LTD.
 Kingston Bussines Centre Unit1
 Fullers Way South
 Chessington KT9 1DQ