



1. Coping Stones.
2. Expanding tape.
3. Stop bead with mesh or undersill (T-shape) bead.
4. Insulation Adhesive.
5. Insulation.
6. Mechanical fixing
7. Basecoat + Fibreglass mesh.
8. Topcoat.

DRAWING TITLE: External insulation installed to a parapet wall with coping stones finish



DRAWING No: EP - 025

DATE: 30-09-2014

SCALE: NTS

\*For fixing patterns, please refer to relevant diagrams.

EWI Pro Insulation Systems LTD.  
 Kingston Bussines Centre Unit1  
 Fullers Way South  
 Chessington KT9 1DQ