



1. Protruding brick plinth.
2. Uprand verge trim screwed to masonry.
3. Expanding tape.
4. Starter track or Clip-on profile.
5. Insulation Adhesive.
6. Mechanical fixing.
7. Insulation.
8. Basecoat + Fibreglass mesh.
9. Topcoat.

DRAWING TITLE: External insulation installed to a protruding masonry plinth.



DRAWING No: EP - 034

DATE: 20-03-2019

SCALE: NTS

*For fixing patterns, please refer to relevant diagrams.

EWI Pro Insulation Systems LTD.
 Kingston Bussines Centre Unit1
 Fullers Way South
 Chessington KT9 1DQ