



Notes:  
 Adhesive needs to cover 30-40%  
 off the back of the board.

- 1. Insulation slab.
- 2. Insulation dot-n-dabs.
- 3. Insulation perimeter.

DRAWING TITLE: Board adhesive spread using the adapted envelope and dot-n-dab method



DRAWING No: EP - 038

DATE: 01-05-2014

SCALE: NTS

\*For fixing patterns, please refer to relevant diagrams.

EWI Pro Insulation Systems LTD.  
 Kingston Bussines Centre Unit1  
 Fullers Way South  
 Chessington KT9 1DQ