



Notes:  
 100% of the board needs to be covered  
 with at least 5mm thickness.

- 1. Insulation board.
- 2. Insulation Adhesive.

DRAWING TITLE: Board adhesive spread using the notched trowel method



DRAWING No: EP - 039

DATE: 01-05-2014

SCALE: NTS

\*For fixing patterns, please refer to relevant diagrams.

EWI Pro Insulation Systems LTD.  
 Kingston Bussines Centre Unit1  
 Fullers Way South  
 Chessington KT9 1DQ