



- | | |
|--|--|
| <ul style="list-style-type: none"> 1. Insulation. 2. Basecoat and mesh. 3. Render/top coat. 4. Fixing. 5. Starter track with clip on profile. 6. Expansion tape. 7. XPS Boards fully bonded (Aquabase). 8. XPS Insulation. | <ul style="list-style-type: none"> 9. Mechanical fixings (Recommend one per 300mm Centers). 10. Aquabase Scrim + Mesh. 11. Topcoat (Mosaic or Silicone). 12. Drainage Gravel or Suitable drainage strategy. 13. Render Underside or Close off With Starter Rails. |
|--|--|

DRAWING TITLE: Base profile with an insulated plinth and insulation system installed below ground level



DRAWING No: EP - 004

DATE: 09-02-2022

SCALE: NTS

REFERENCES:
INCA WRD-B001

EWI Pro Insulation Systems LTD.
Kingston Bussines Centre Unit1
Fullers Way South
Chessington KT9 1DQ