

WEATHERING RISK

RISKS: • WATER INGRESS INTO INSULATION FIXINGS

SOLUTIONS:

• ENSURE FIXINGS ARE SEALED AGAINST RENDOR WITH EPDM GASKETS OR PROPERTY WATER PROOF SEALANT

- 1. Use combination of insulation and render board as box pattress.
- HD Insulation block-Use XPS insulation.
- 3. Use swifix fixings.

DRAWING No: EP-058

DATE: 09-02-2022

SCALE: NTS

REFERENCES: WRD-EFF001



EWI Pro Insulation Systems LTD. Kingston Bussines Centre Unit1 Fullers Way South Chessington KT9 1DQ

