



Notes:

Stress patches cut to fit around all openings. Installed at 45°. Follow stress patch detail on around all service box corners and vent holes.

DRAWING TITLE: Typical Stress Patch detailing

DRAWING No: EP - 046

DATE: 01-05-2014

SCALE: NTS

*For fixing patterns, please refer to relevant diagrams.



EWI Pro Insulation Systems LTD.
Kingston Business Centre Unit1
Fullers Way South
Chessington KT9 1DQ