


Gutter laid to slight fall to discharge into gutters

Heat Loss Pathways

Loft insulation: between joists & over joists

Heated space

Option 1:  
EWI stops above upper storey ceiling level



EWI system to extend to at least the top of the loft insulation level:

1. Substitute lead flashing to be ground into existing substrate and fixed with clips and dressed over verge trim
2. Compressible Sealing tape between substrate and verge channel
3. Flexible continuous (i.e full width of elevation) waterproof membrane sandwiched between channel and verge trim, dressed over EWI
4. Insulated Fascia ( $R \geq 0.6 \text{ m}^2\text{K/W}$ )

DRAWING TITLE: Scenario 2 -Solution B Gable verge horizontal to unheated roof space

DRAWING No: EP-064

DATE: 09-02-2022

SCALE: NTS

REFERENCES:



EWI Pro Insulation Systems LTD.  
Kingston Business Centre Unit1  
Fullers Way South  
Chessington KT9 1DQ