



1. Grind 10mm x 30mm into existing mortar pointing if possible and install substitute lead flashing with clips. If this is not possible, remove all cement and repoint once substitute lead flashing has been installed
2. Compressible sealing tape between verge channel and substrate
3. Verge union double silicone sealed
4. Flexible continuous (i.e full width of elevation) waterproof membrane sandwiched between channel and verge trim, dressed over EWI
5. Insulated Fascia ($R \geq 0.6 \text{ m}^2\text{K/W}$) if heated roof space

DRAWING TITLE: Scenario3-Solution B1 Gable verge following apex (Flush Verge)



DRAWING No: EP-066

DATE: 11-02-2022

SCALE: NTS

REFERENCES:

EWI Pro Insulation Systems LTD.
Kingston Business Centre Unit1
Fullers Way South
Chessington KT9 1DQ